


ASSEMBLY INSTRUCTIONS FOR ROLL-10



KEY DISRIPTION	PART#	QUANTITY
A TOP	1	1
B RIGHT PARTITIONS	2	1
C LEFT PARTITIONS	3	5
D BACK PANEL WITH NOTCHES	4	1
E BACK PANEL WITHOUT NOTCHES	5	1
F BLUE PANEL WITH PERCH AND NEST BOTTTOM OPENING	6	6
G BLUE PANEL WITH NEST BOTTOM OPENING	7	4
H SHORT PERCH ARMS	8	4
I PERCHES	9	2
J CLEAR RUBBER FLAPS	10	2
K NEST BOTTOMS	11	10
L ROLL OUT BOTTOMS	12	10
M HARDWARE PACK ^{**}	ROLLHP	SEE BELOW

CONTENTS:



3/16" POP RIVETS	73
10-24 X 1/2 BOLTS	12
10-24 X 3/4 BOLTS	24
10-24 NUTS	36
1/4-20 X 1 1/4 HEX BOLTS	8
1/4-20 NUTS	8
HANGING BRACKETS	2

^{**} EXTRA HARDWARE MAY BE INCLUDED


STEP 1 LAY PANELS ON BACK (LONGEST SIDE) AND ATTACH TOP USING THE POP RIVETS PROVIDED



STEP 2 FLIP NEST ON FRONT EDGE (SHORT SIDE) AND ATTACH BACK PANELS TO NEST. PANEL WITHOUT NOTCHES IS TO BE INSTALLED ON BOTTOM EDGE ,AND PANEL WITH NOTCHES IS TO BE ATTACHED ABOUT MID WAY UP THE BACK OF NEST.




NOW IS ALSO A GOOD TIME TO ATTACH HANGING BRACKETS ON LEFT AND RIGHT BACK CORNERS WITH 10-24X1/2 BOLTS



WHITE CIRCLES INDICATE WHERE NOTCHES IN PANELS ARE

STEP 3 STARTING FROM LEFT TO RIGHT ALONG THE BOTTOM EDGE, BOLT (FINGER TIGHTEN ONLY) THE LOWER HOLES OF EACH PANEL WITH THE 10-24 X 1/2 BOLTS PROVIDED, STARTING WITH PART# 7 FIRST, THEN PART#6, THEN PART#7 THEN AGAIN PART#7 AND FINISH WITH PART#6, REPEAT THIS PROCESS ON THE NEXT SET OF HOLES ABOVE. AFTER ALL THE BOTTOM HOLES OF THE BLUE PANELS ARE IN PLACE, LAY THE CLEAR RUBBER FLAP (PART#10) OVER THE BLUE PANELS AND LINE UP THE HOLES IN THE FLAPS WITH THE TOP HOLES OF THE BLUE PANELS. USE THE 10-24 X 3/4 BOLTS TO ATTACH THE PANELS, FLAPS AND THE UPRIGHT PARTITIONS TOGETHER. ONCE THE PANELS ARE BOLTED, GO BACK AND RETIGHT ALL THE BOLTS.




PART#6 BLUE PANEL WITH PERCH AND NEST BOTTOM OPENING




PART# 7 BLUE PANEL WITH NEST BOTTOM OPENING


STEP 4 USING THE 10-24X1/2" BOLTS PROVIDED, ATTACH PART#11 (SHORT PERCH ARMS) TO UPRIGHT PARTITIONS 2 & 5. PERCH ARMS GO THROUGH FRONT BLUE PANELS BUT NOT THROUGH BACK PANELS



STEP 5 LAY THE PERCHES ON THE PERCH BRACKETS WITH THE PRE DRILLED HOLES TOWARD THE FRONT EDGE OF THE BRACKET. USE THE 1/4-20 X 1 1/4" HEX BOLTS TO ATTACH PERCHES.



STEP 6 PLACE NEST BOTTOMS INTO COMPARTMENTS WITH BENDS AGAINST PARTITIONS



STEP 7 ROLL OUT NEST BOTTOMS ARE INSTALLED BY PUTTING THEM THROUGH THE BACK OF THE NEST SO THEY GO THROUGH THE FRONT BLUE PANELS AND THE BACK RESTS ON THE TOP OF THE BACK PANELS. NOTE WHEN PUSHING THE BOTTOMS THROUGH THE FRONT PANELS IT WILL LIFT THE VINYL STRIPS UP CREATING A WASTE GUARD FOR THE BOTTOMS.

